
Ordering Information

Accessories



Assembly tool



| HX-TT-1 | Assembly and crimp tool for NP3TT-1/AU |
|--------------|--|
| HX-R-BNC | HEX crimp tool for NP3TT-P* |
| DIE-R-BNC-PJ | HEX crimp die for NP3TT-P* (5.4 mm) |
| HTXP | Hand tool to tighten the PX and XX-bushing |
| HTPXS | Hand tool to hold shell of PX Plug |